



VELO CO₂ cooling reuse proposal

Bart Verlaat

7 June 2019


VELO CO₂ cooling plant in LHCb



CO₂ unit^{ologies}


Freon injection

Accumulator




Condensers

Valves



CO₂ pumps

Freon unit




Expansion valves



Freon buffer



Main compressor
(Water cooled system)




Back-up compressor
(Air cooled system)

PLC-rack

Touch screen




PLC rack next to
CO₂ system



Rear side

- All cooling EDMS documents (not complete)
 - <https://edms.cern.ch/ui/#!/master/navigator/project?P:1405012445:1405012445:subDoCS>
- VTCS technical design Report:
 - <https://edms.cern.ch/document/1056946/3.0>
- Gathered electrical information
 - <https://cernbox.cern.ch/index.php/s/mTbJ8niDSARwtQ9>
- Drawings of the system:
 - <https://www.nikhef.nl/pub/departments/mt/projects/lhcb-vertex/pdf/TVC-COOLING/>
 - Assembly drawings:
 - TVC60: CO2 rack
 - TVC66: Chiller rack
 - TVC70: Integration situation
- Photo Archive:
 - <https://www.nikhef.nl/pub/departments/mt/projects/lhcb-vertex/production/Coolingparts/>
 - <https://www.nikhef.nl/pub/departments/mt/projects/lhcb-vertex/production/Freonparts/>

Overall size of the set-up



Reuse of the VELO CO₂ cooling

- The VELO cooling has been functioning well till December 2018
- All components are in a good shape and can be used to continue running.
- A few things need to be changed for future use:
 - The control software must be re-written to UNICOS standards to guarantee safe operation by new users to streamline the use of the unit according the EP-DT standards for cooling systems. Only like this we can guarantee a safe use for new users.
 - New insulation: The current insulation is worn out and need to be re-applied.
- The VELO has back-up hardware to have guaranteed a 24/7 operation in LHCb
 - This hardware is not needed and can be taken out
 - This will help a lot in simplify the new control and hence commissioning.
 - The application of the new insulation is much simpler, less to insulate, better access.
- All cabling between the cooling and racks and plants are by connectors
 - The same set-up is needed, this takes space
- The system is designed for long distance transfer lines
 - The new lab can be remote from the plant (~50m)
 - There are 2 individual plants, 2 locations can be served with the transfer lines




Proposal for reuse:


- In order to see the effect the unnecessary back-up hardware is removed.
- In order to make it the most simple set-up the injection lines of the back-up system will be reused and will be connected to the main condensing unit.
 - The injection of the main chiller was too complex and was tricky to tune.
- The removal of all back-up hardware gives now a reasonable access to apply the insulation
- Further optimization of space can be made by cutting some more pipes.
 - Only sections with connectors are removed
 - This cutting requires some welding
 - A few valves can also be taken out to simplify the use and insulation, might also require some welding
- The reuse of the electronics must be reviewed by control experts
 - Documentation has been retrieved
 - Is this sufficient to understand the cabling spaghetti?
- The unit needs thorough cleaning
 - Remove of insulation remains
 - Remove of calcified deposit due to condense water



The elements..




The units after stripping back-up HW







For the trash can.....



The unit needs thorough cleaning





Main chiller and hardware which has been removed


Temperature
sensor labeling:

(101) = SA_TT101
(102) = SA_TT102
.....
(122) = SA_TT122


(xxx) = Internal rod sensor

SA_S.0 labeling:

S.16.01 = SA_S.16.01



Red zones are removed to simplify and create insulation access



Red zones are removed to simplify and create insulation access

Combined new chiller


Temperature
sensor labeling:

(101)=SB_TT101
(102)=SB_TT102
.....
(122)=SB_TT122


(xxx) = Internal rod sensor

SB_S.0 labeling:

S.16.01 = SB_S.16.01



Former back-up chiller
(simplicity)



Former main chiller
(high capacity)